

TUESDAY TECH TIP

valspar
REFINISH

DBNZ Tech Tip of The Week

For Customized SOP style documents ask DBNZ to do an ELEVATE version for your paint shop.

This incorporates the products and equipment that are used in your shop to create best practice as set by product TDS, Shop Owners and Paint Shop staff.

This will help to bring the understanding of what standards of repair are to be expected by all parties within the repair process, limit down time and speed up process.



Z777 **Mid Coat Adhesion Promotor**

Z777 is a water white clear 1k adhesion promotor for OEM/ Basecoat Clearcoat Finishes.

Ready for use (*RFU*) straight from the tin.

It is designed for application over suitably prepared OEM substrates, 2K topcoats or primers, to enhance topcoat adhesion and minimise surface preparation.

Z777 can be over-coated with Valspar Refinish **888** Series Basecoat or **862** Series 2K Polyurethane topcoat.

Note:

- For paint to adhere to any surface, that surface first needs to be well cleaned, when it comes to adhesion promotors it is even more crucial to ensure the substrate is thoroughly cleaned, e.g. under bonnets, tight door jams and OEM blend panels.
- Where possible, prepare any areas by scuffing with P600/800 or Grey Scotchbrite, then thoroughly re-clean. (e.g. a quality wax and grease remover)
- **Do-not allow** any cleaning solutions to air dry on the surface, always wipe the substrate dry with a clean cloth while the cleaner is still wet.
- **Z777** is not intended to be a plastic adhesion primer.

Z777

Application: 1 x medium wet coat.
Flash Time: 15 minutes before topcoating. (@25°C)
Gun Set Up: Gravity, Conventional/HVLP - 1.3mm - 1.4mm
Air Pressure: 2.0 bar (30psi)

For further information refer to the product TDS or consult your Valspar Refinish Representative.